

Manual: Wireless Motion Sensor Alarm

Instructions: Unpack the product and insert 4 AA batteries into the sensor. Pull out the protective paper from the remote control. Place the sensor in a location with a clear view of the area where an intruder might come through. Before securing it, we recommend testing the placement. Mark the holes for the bracket, drill the holes, insert the anchors, and secure the bracket with screws. If attaching the product to wood or drywall, you can use screws only. Attach the sensor to the bracket, aim it at the desired location, and test its functionality by turning it on with the remote control and walking through the area where the sensor is directed. To turn off the alarm, press the button on the remote control while aiming it at the sensor.

Instrukcja: Wireless Motion Sensor Alarm

Instructions: Unpack the product and insert 4 AA batteries into the sensor. Pull out the protective paper from the remote control. Place the sensor in a location with a clear view of the area where an intruder might come through. Before securing it, we recommend testing the placement. Mark the holes for the bracket, drill the holes, insert the anchors, and secure the bracket with screws. If attaching the product to wood or drywall, you can use screws only. Attach the sensor to the bracket, aim it at the desired location, and test its functionality by turning it on with the remote control and walking through the area where the sensor is directed. To turn off the alarm, press the button on the remote control while aiming it at the sensor.

Használati útmutató: Vezeték nélküli

Mozgásérzékelős Riasztó

Utasítások: Bontsa ki a terméket és helyezzen be 4 db AA elemet a szenzorba. Húzza ki a távirányító védelmi papírját. Helyezze el a szenzort egy olyan helyre, amelyről jó kilátás nyílik arra a területre, ahol egy behatoló beléphet. A rögzítés előtt javasoljuk a elhelyezés tesztelését. Jelölje meg a tartó lyukait, fúrja ki a lyukakat, helyezze be a tipliket, majd rögzítse a tartót csavarokkal. Ha a terméket fa vagy gipszkartonhoz rögzíti, akkor csak csavarokat használhat. Rögzítse a szenzort a tartóra, célozza meg a kívánt helyre, és tesztelje a funkcionalitását, bekapcsolva a távirányítóval, majd haladva a területen, amerre a szenzor irányul. Az riasztó kikapcsolásához nyomja meg a gombot a távirányítón, miközben a szenzorra irányítja.

Instrucțiuni: Alarm Wireless cu Sensor de

Mișcare

Instrucțiuni: Deschideți produsul și introduceți 4 baterii AA în senzor. Trageți hârtia de protecție de pe telecomandă. Plasați senzorul într-un loc cu o vedere clară asupra zonei în care un intrus ar putea intra. Înainte de fixarea sa, recomandăm testarea poziționării. Marcați găurile pentru suport, perforați găurile, introduceți diblurile și fixați suportul cu șuruburi. Dacă fixați produsul pe lemn sau gips-carton, puteți utiliza doar șuruburi. Afixați senzorul pe suport, îndreptați-l către locul dorit și testați funcționalitatea sa, pornindu-l cu telecomanda și parcurgând zona în care este direcționat senzorul. Pentru a opri alarma, apăsați butonul de pe telecomandă îndreptându-l către senzor.